

Draft Mass Balance Scenarios						
Current Conditions for August 2012 Synoptic Sample (624 cfs @ Parma)						
	Scenario 1	Scenario 2	Scenario 3	Scenario 4	Scenario 5	Scenario 6 ¹
Point Source	0.35	0.35	0.35	0.35	0.35	0.35
Nonpoint Source	0.07 15-mile = 0.3 Indian = 0.07 Dixie = 0.07	0.07 15-mile = 0.3 Indian = 0.35 Dixie = 0.07	0.07 15-mile = 0.3 Indian = 0.35 Dixie = 0.35	0.07 15-mile = 0.35 Indian = 0.35 Dixie = 0.35	0.07 15-mile = 0.35 Indian = 0.35 Dixie = 0.35	0.07 15-mile = 0.35 Indian ¹ = 0.35 Dixie = 0.35
Groundwater/ Unmeasured	0.07	0.07	0.07	0.07	0.12	0.12
TP @ Parma	0.07	0.09	0.18	0.19	0.2	0.2

¹Entire Indian Creek delivered to LBR and load reduced from Dixie Drain.